



Photos: NTB scanpix

EASY PREPARATION OF SKIS AND SNOWBOARDS

If you are tuning skis you have to fasten the **ski brake retainers** before you start (T0165).



Sharp edges are like new tires for the car. You feel more secure and confident. The equipment will respond more precisely to your skiing and riding movements, especially when the snow is hard.

On the Hill Diamond Disk Tuner (TA3004). Pocket size file guide for easy accurate side and base edge filing. Fixes your edges quickly!



When it comes to smooth gliding, unwaxed skis and boards can be compared to bicycling with not enough air in the tires. The F4 Glide Wax gives smoother turns with less effort, more glide on the flats, and in general a better experience!



F4 - Handy Easy Wax
A high quality water-repellant liquid wax for all snow conditions. The bottle has a wide foam applicator for quick and precise application and a felt polisher in the bottom.



Apply and go!

FOLLOW THESE EASY STEPS:

- Shake the bottle and then press the sponge against the base. Distribute evenly.
- Let the wax dry for about 3 to 4 minutes and polish with the felt in the bottom.



www.swixsport.com

SWIX®